

	EN	ES	IT	NL	DA	NO	AR
	FR	DE	PT	EL	FI	SV	RU
CS	HU	LV	PL	BG	SL	KO	TH
ET	LT	MT	RO	SK	TR	MS	ZH

Cat I



### Europe

Ansell Healthcare Europe NV

Blvd International, 55

1070 Brussels, Belgium

☎ +32 2 528 74 00 📠 +32 2 528 74 01

[www.anselleurope.com](http://www.anselleurope.com)

### United States

Ansell Healthcare

200 Schulz Drive, Red Bank NJ 07701

☎ +1 800 800 0444 📠 +1 800 800 0445

[www.ansellpro.com](http://www.ansellpro.com)

### Japan

Ansell Japan Ltd.

Tokyo, Japan

☎ +81 3 5805 3781

### Malaysia

Ansell Services (Asia) Sdn Bhd

☎ +60 3 5541 9797

### Canada

105 Lauder Street, Cowansville J2K 2K8

☎ +1 800 363 8340

### Australia

Ansell Limited

Level 3, 678 Victoria Street,

Richmond, Vic, 3121

☎ +61 1800 337 041 📠 +61 1800 803 578

[www.ansellasiapacific.com](http://www.ansellasiapacific.com)

# Ansell

## ANSELL ECONOHANDS

**A. Use**

This Instruction for Use note is to be used in combination with the specific information that is mentioned on or inside each packaging enclosure.

These gloves are designed to protect the hands against minimal risks which cannot cause irreversible lesions to the wearer's skin.

They are in conformity with, and are marked per the requirements of the European Directive 89/686/EEC and its amendments.

Gloves which are accompanied with the pictogram which designates contact with foodstuffs, are also in conformity with the European Regulations 1935/2004 and 2023/2006 as well as with all applicable National Regulations for Food-contact materials.

Please ensure the gloves are used only for the designated purposes.

Explanation of pictograms :



For more detailed information on the glove's performance and to obtain a copy of the Conformity Declaration, please consult Ansell.

**B. Precautions for use**

1. Before usage, inspect the gloves for any defects or imperfections. If the gloves are ripped or punctured during use, dispose of them immediately. If in doubt, do not use the gloves, get a new pair.
2. Avoid wearing gloves which are dirty on the inside – they may irritate the skin, causing dermatitis or worse.
3. Contaminated gloves should be cleaned or washed before removal.
4. The gloves should not be used for protection against serrated blades or when there is a risk of entanglement with moving machine parts.
5. The gloves should not come in contact with a naked flame.
6. Not all gloves that are suitable for contact with foodstuffs can be used against all foodstuffs. Some gloves may show excessive migration towards certain types of foodstuffs. To know which restrictions apply and for which specific foodstuffs the gloves can be used, please obtain advice from the Ansell technical department or consult the Ansell Food Conformity declaration.
7. If gloves are marked, the printed surfaces shall not come in contact with food.

**C. Ingredients / Hazardous ingredients**

Some gloves might contain ingredients which are known to be a possible cause of allergies in sensitised persons, who may develop irritant and/or allergic contact reactions. If allergic reactions should occur, obtain medical advice immediately.

For more information, please contact Ansell's Technical department.

**D. Care instructions**

**Storage:** Keep away from direct sunlight; store in a cool dry place.

Keep away from ozone sources or naked flame.

**Cleaning:** The gloves are not designed to be laundered.

**E. Disposal**

Used gloves may be contaminated with infectious or other hazardous materials.

Dispose of according to Local Authority Regulations. Landfill or incinerate under controlled conditions.